DIGITAL DC CENTRE

The Worldwide PhotoBooth Manufacturers

the STRIP by DIGITAL DC CENTRE

EUR-USA v8.1

USER MANUAL

America:
Digital Centre America, Inc.
14271 SW 120th Street Unit #109
USA, Miami, FL 33186

Sales:
Ph: +1.305.387.5005
sales@dc-image.com

Tech Support:
Ph: +1.305.387.5115
support@dc-image.com

Europe:
Digital Centre
Pol. Ind. Sant Isidre
C/ Puigmal, 20-22 St. Fruitós
08272, BARCELONA. Spain

Ph: +34.938.748.158
info@dc-image.com





www.digital-centre.com

Copyright and Trademarks

This manual contains materials protected under International copyright Laws. All rights reserved. No part of this manual may be reproduced, transmitted or transcribed without the expressed written permission of the manufacturer and author of this manual.

The information of the products in this manual is subject to change without prior notice and does not represent a commitment on the part of the vendor. Who assumes no liability or responsibility for any errors that appear in this manual.

CONTENTS

1. Safety Instructions----------6-7
2. Specifications----------8
3.Unpacking · Installation----------9-10
4.Features----------10
4.1 Service Control Panel----------10
4.2 Power Switch----------10
5.Connections----------11-20
5.1 Control Board----------11
5.2 Accessing the Control Board----------12-15
5.3 RJ45 Ethernet (internet)----------15-16
5.4 PC wiring----------16
5.5 Printer----------17
5.6 General----------18
5.7 Monitor----------19-20
6.Printer----------21-32
7.Playing----------33-41
8.Customized----------42-60
8.1 Structure----------42-43
8.2 Logo----------44-45
8.3 Welcome/Bye----------46-51
8.4 Text----------52-53
8.5 Music----------54
8.6 Frames----------55-60
8.7 Advertising Photos----------61-64
9.Uploading----------65
10.Downloading----------66
11.Setup menu----------67-74
11.1 Products&Prices----------68
11.1.1 Extra Copies----------69
11.2 Rentals----------70
11.3 Customize----------70-73
11.3.1 Logo----------71
11.3.2 Text----------72
11.3.3 Date----------72
11.3.4 Welcome/Bye----------73
11.3.5 Frames----------73
11.4 Options----------74
11.5 Camera----------74

12.Internet----------75-77
12.1 Player.Get Your Picture----------75-76
12.2 Owner.Prepare USB-Stick/Event----------76-77
13.Troubleshooting----------78-96
13.1 Uploading The Logo----------81-82
13.2 Hard Drive----------83-86
13.3 Boot DVD----------87
13.4 Dongle Error----------88
13.5 Camera Error----------89
13.6 Touch Screen Error----------89
13.7 Printer Error----------90-91
13.8 No Signal----------92
13.9 Control Board Error----------93
13.10 Image Adjunting----------94-96
14.Characteristics----------97-101
14.1 Control Board Diagrams----------97
14.2 Decals----------98
14.3 Spare Diagrams----------99
14.4 Parts List----------100-101
15.Notes----------102
16.Annex 1: myphotocode.com Tutorial----------103-124

1-SAFETY INSTRUCTIONS

The following directions must be followed carefully for safe use, to prevent personal injuries, and damage to the equipment.

Please read this entire manual before initial use and store it in a convenient location for on easy access.

⚠ **WARNING:** To ensure safe operation, observe specifications, notices and cautions in this document. Digital Centre Accepts no liability for damage or injuries from improper use of this product.

⚠ **WARNING:** Prevent electrical shock and equipment damage. Before connecting or disconnecting cables and/or changing the paper, disconnect power cord from the A/C outlet.

⚠ **WARNING:** Prevent shock hazard and damage. Only plug the power cord into a **220 volts (110 volts for USA) grounded A/C outlet.**

⚠ **WARNING:** Do **not** touch exposed wires or moving parts such as power supply modules and the control board. Touching these parts could cause electric shock or other injury, data loss, and/or printer malfunction.

⚠ **WARNING:** Only use Mitsubishi CK9046(DC) paper / ink ribbon set in the printer. Use of other paper / ink ribbon will cause software malfunction, poor image quality, and/or printer damage.

⚠ **WARNING:** Do **not** touch the thermal print head, or head area of the printer. The print head operates at an extremely hot temperature. Touching it might cause burns or other injury.

⚠ **WARNING:** Follow the directions in the Mitsubishi manual when cleaning the printhead. Do not use cotton, wool or other fabric swabs. The lint left behind poses a fire hazard.

NOTICE: Read additional **Warnings** in Mitsubishi Printer Manual.

⚠ **WARNING:** The printers are not interchangeable.

⚠ **DANGER:** Tipping Hazard! Photo Booth may pose danger to small children and/or pets. Unplug the power cord from the A/C outlet immediately if the Photo Booth tips over.

⚠ **WARNING:** Use only original parts from Digital Centre.

Use only original parts from Digital Centre. Use only original parts for your photo booth from Digital Centre. Non original parts may compromise the use of the photo booth and may create a malfunction and cause serious damage. Using different components, changing wiring, or altering the photo booth in any fashion will void the warranty.
Digital Centre is unable to assist any customer that has changed, modified, or altered the photo booth using non original parts. We cannot provide a guarantee or service for products that are not original parts from Digital Centre.

DANGER: Power Off the Photo Booth immediately if any of the following occurs:

- Smoke
- Unusual Odor
- Unusual Noise
- Water or other Liquids spill inside the Photo Booth
- Physical Damage

DANGER: Do not place or store the Photo Booth in wet or extremely humid areas, in direct sunlight, near an open flame or heater, and/or swimming pools. Avoid Condensation.

Danger: Operate the Photo Booth in locations with ambient temperatures of 5°C – 40°C (41°F – 104°F)

DANGER: Install the Photo Booth on a flat, even and, clean surface.

DANGER: Repairs should only be made by qualified technicians.

WARNING: Indoor Use Only

MAINTENANCE: Cleaning: Use only a clean, dry, soft cloth. If necessary use a damp cloth and/or neutral detergent. Do not use window cleaner or any other alkaline cleaners.

2-SPECIFICATIONS

the STRIP by DIGITAL DC CENTRE

CLOSED

Power Supply: AC 220V 50/60 Hz(110V for USA)
Power Consumption: 260W
Weight = 113Kg / 250 lbs.

Nominal fuse rating= 6 Amps
Monitor: LCD Monitor 19'' HANNS (4u)
Printer: Mitsubishi CP9550 Dye Sublimation Photo Printer

Specifications may change at any time without prior notice.

3-UNPACKING · INSTALLATION

These are the accessories included with your new Digital Centre Photo Booth:

Manual



Keys

Power Cord

Boot DVD



Warning: Movement of the photo booth requires assistance from two or more people.

· Unwrap and remove all packaging materials. Remove screws and metal holding plates that attach the Photo Booth to the skid.

· Access to the printer and the USB port of the computer is on the left. Unlock and open this side service door and then remove the protective polystyrene foam block before first use.

· The keys for the service door, service panel, manuals, and power cord are located in the picture chute on the right side of the Photo Booth.

· Inspect the wiring harnesses for disconnected plugs.

Plug the power cord into the socket underneath the Photo Booth. Slide the power switch to the "ON" position.

The photo booth has at the rear carries two wheels to move.

4-FEATURES

4.1 SERVICE CONTROL PANEL



1. Volume Control lever
2. Menu (Yellow Button): It enters setup Menu and allows options such as pricing, logos, camera adjustments, and features to be changed.
3. Accounts (Black Button): It prints detailed vending report including number of prints available.
4. Credit (Red Button)
5. Coin Counter

4.2 POWER SWITCH

The Power Switch is located underneath the cabin. It contains a Fuse and a power cord socket.

5-CONNECTIONS

5.1 CONTROL BOARD

CONTROL BOARD (DC-EVO-V3.0)



RS232. Serial Cable. From Control Board to PC.
JP7. Bill Acceptor Cable. From Control Board to Bill Acceptor.
CN1 Power Supply at 230 volts (115 volts for USA).
Jack Stereo. From Control Board to PC
F1. We need 1A fuse here to run the Control Board.
JP3. Speakers. JP3 gives us the volume control.

POTENT R24: We connect here the main cable from Control Board to Push Buttons + Speakers.

5.2 ACCESSING THE CONTROL BOARD

Open the Bottom Left Door (Photo Slot)

2 Open the back door



*There are 2 keys 1314 included on your photobooth

Remove the 2 nuts that hold.
(The front monitor chassis with the back chassis)

3



CONTROL BOARD (DC-EVO-V3.0)

4

Open the STRIP, as if we open a door....

WARNING!. Do not open more than 80 °.
Attention, it is a very delicate operation.

CONTROL BOARD (DC-EVO-V3.0)



5.3-RJ45 ETHERNET (INTERNET)

P.9 Cable RJ45 Ethernet (internet)
(Not included)

Internet connection

- Check the distance between the internet connection and the position of your photobooth in the room.
- Ensure you have a RJ45 ethernet cable that is long enough.
- Pull out the back door
- Take the cable (RJ45 ethernet) and plug it into the ethernet "hold" of your PC.

WARNING:

- The cable just can only be plugged into one position.



P.9 Cable RJ45 Ethernet
(internet)

5.4-PC WIRING



P.1 Main Power Cable
P.2 Serial Cable From PC to Control Board. STRIP (200 cm - Inch 78,74)
P.3 Jack Stereo Cable. (180 cm - Inch 70,87)
P.4 VGA Cable 4 to Monitors
P.5 Empty
P.6 Empty
P.7 USB Extension AM/AF From Dongle to PC. (180 cm - Inch 70,87)
P.8 USB Cable From Printer to PC AM/BM. (180 cm - Inch 70,87)
P.9 Cable RJ45 Ethernet (internet)
P.10 USB Extension AM/AF From Camera to PC. (180 cm - Inch 70,87)
P.11 USB Cable AM/AF - Panel. STRIP (50 cm - Inch 19,69)

5.5 PRINTER



PRINTER WIRING

P.1 Main Power Cable
P.7 USB Extension AM / AF From Dongle to PC
(180 cm - Inch 70,87)
P.8 USB Cable From Printer to PC AM/BM. (180 cm - Inch 70,87)

5.6 GENERAL



COMPONENTS

1. Printer Mitsubishi CP9550DW-DC
2. PC HP C2D
3. PC HP Holder. (RAW METAL)
4. Wood Printer Base. STRIP (RAW)
5. Wood PC Base. STRIP (RAW)
6. Printer Holder CP9550DC. (RAW METAL)
7. Transformer 2A 12V
8. Cable From Control Board to Service Panel + Speakers + Led.
9. Service Control Panel - Model 2

PC WIRING

P.1 Main Power Cable
P.7 USB Extension
AM / AF From Dongle to PC.
(180 cm - Inch 70,87)

5.7 MONITORS



COMPONENTS

10. Monitor 19" Holder. STRIP (RAW METAL)
11. Tilting Camera Back Holder. (RAW METAL)
12. Full HD Camera
13. LCD Monitor 19" HANNS
14. Touch Cable From Touchboard to USB PC &12V Adaptor (200cm - Inch 88.58)
15.Touch Cable From Touchboard to USB PC + 12v Adaptor Together (225cm - inch 88.58)
16. Led Cable. (BLACK) (53 cm - Inch 20,87)

PC WIRING

P.1 Main Power Cable
P.4 VGA 4 Cable to Monitor.



COMPONENTS

17. Speakers 1W.
(7,5 cm - Inch 2,95)
18. Bill Acceptor Optional

PC WIRING

P.1 Main Power Cable
P.4 VGA 4 Cable to Monitors

6-PRINTER

WARNING: The printers are not interchangeable

·Protective Measures

This printer is designed to operate with Photo Booth systems. Do not remove any inside components. Do not try to repair or manipulate them. Before printing, install an Ink sheet and paper.

Never insert any object into the unit.
Foreign objects of any kind inserted into this unit is safety hazard and can cause extensive damage.

Do not place anything on the digital color printer.
Heavy objects placed on the digital color printer can cause damage or obstruct proper ventilation.

Do not remove the cabinet.
Touching internal parts is dangerous, and may lead to malfunction. Contact the sales dealer to carry out internal checks and adjustments. Before opening the cover for eliminating a jammed paper, etc ... , be sure to disconnect the power cord plug.

When transporting the unit.
When transporting the unit, remove the ink sheet and print paper from the unit.

Be careful around print paper exit slot.
Do not insert your hand or any material into the paper exit slot during printing.
Do not touch the cutter blade inside the paper exit slot. Otherwise, your finger will be injured.

Do not touch the thermal head.
Do not touch the thermal head (located inside the unit).
The thermal head is heated to a high temperature. This may cause injury.

Ink sheet and paper print supply.
Use only the ink sheet and paper supplied by Digital Centre, otherwise the Photo Booth system will not work, and Digital Centre does not assume any responsibility for damages or injuries.

FEATURES & FUNCTIONS

FRONT PANEL



1 · POWER BUTTON
Use to switch the power ON and OFF.
Press to turn on power. Press again to turn off power.

2 · PRINT OUTLET
The printed paper comes out here.

3 · DOOR OPEN BUTTON
When you press this button while the power is on,the door will open in about five seconds.

4 · DOOR
Open this door when installing print paper or ink ribbon. Press the DOOR OPEN button 4 to open the door.

5 · POWER INDICATOR
When the power is turned on, the indicator illuminates.

When a paper jam happens occurs or when the door is open.

6 · PAPER/INK RIBBON INDICATOR
When an error concerning the ink ribbon or print paper happens occurs, this indicator illuminates or blinks

7 · DATA INDICATOR
This indicator blinks during data transfer. It illuminates during printing.

8 · READY INDICATOR
This indicator illuminates when this unit is ready to accept the data. It also illuminates during data transfer. It blinks during print canceling procedure.

9 · COOLING INDICATOR
When the unit is overheated, this indicator blinks.

10 · CANCEL BUTTON
Press this button for a little over 1 second to cancel continuous printing. After the button is pressed, the printing process is canceled.

11 · FEED & CUT BUTTON
Hold down this button for a little over 1 second and the printer paper is fed and cut.

SIDE AND REAR PANEL



1 · USB TERMINAL
Use to connect the USB cable.

2 · DIP SWITCHES
Never touch this part.

3 · HANDLE FOR TRANSPORTING
When transporting this unit, hold this handle and the lower front part of this unit.

4 · POWER SOCKET (AC LINE)
Use to connect the provided power cord. Insert the cord firmly.

Before Operation

BEFORE PRINTING

1. Install the print paper to this unit. (See below.)
2. Install the ink ribbon to this unit.

INSTALLATION OF PRINT PAPER

·SPACERS

The spacers are attached to the paper flanges. The spacers are necessary, for reasons see the Quick Setup Guide. Remove the cushions put between the paper flange and spacer when using them.

How to attach and remove the spacers
1. Turn the spacer until the latches are unlocked.
2. Remove the spacer with the paper flange's stoppers retracted.

When you use the print paper with the correct spacers that have to be used, attach the spacers to the paper flanges by reversing the removal procedure as shown on the right.



1 **Attach the supplied paper flanges to both sides of the print paper.** When you pinch the latches on the paper flange, the stoppers retract into the shaft. Attach the flanges to the print paper with the stoppers retracted. Make sure that the flanges are attached to the print paper securely, and release the latches.



NOTE
- Be careful not to pinch your fingers.
- Do not remove the sticker on the print paper yet.
- Do not slack the paper. Any slack in the print paper may degrade the print quality.

CAUTION
- When placing the print paper, remove one flange and keep the print paper upright on its side with no flange.
- When you put the print paper sideways, it may roll and fall. This may cause injuries.

NOTE
- Do not touch the thermal head.
- Fingerprints or dust on the thermal head will degrade the print quality.

Before Operation



2 Press the POWER button to turn on the power.



3 Press the DOOR OPEN button to open the door.
Take the ink cassette in the printer out.

4 Install the print paper into the unit. Make sure to install the print paper firmly.



NOTE
Install the print paper into the unit slowly. If it is dropped along the ditches, the unit or accessories may be damaged.

CAUTION
Do not touch the thermal head right after printing because it is extremely hot. Otherwise you may get burned or injured.

NOTE
Note that the thermal head is quite sensitive to static electricity. When you touch the thermal head while carrying static electricity on your body, the thermal head may be damaged.

Before Operation



5 Remove the sticker, insert the print paper between the rollers as shown above, and feed the print paper until it reaches the black cover.

Remove the sticker before inserting the print paper between rollers. Make sure to insert the paper straight.

NOTE
- Keep the roller clean.
- Dirt on the roller may degrade the print quality.

NOTE
- When taking the print paper out, pull it up toward you.
- Make sure to turn on the power before replacing the print paper.
- Make sure to eliminate any slack from the print paper. If you carry out the following steps without eliminating the slack, the print paper may be damaged.

2 INSTALLATION OF INK RIBBON

INSTALLING THE INK RIBBON

After installing the print paper, load the ink ribbon in the ink cassette.
Then install the ink cassette into this unit.

NOTE
- Place the ink cassette on a flat surface, when loading the ink ribbon.
- Select a place that is free of dust when loading the ink ribbon. Dust or dirt settling on the ink ribbon results in a poor print quality.
- Make sure that the shafts of the ink ribbon fit into the ink cassette firmly.



INSTALLING THE INK CASSETTE

1 · Place the ink cassette containing the ink ribbon in the position as shown above.
Place the ink cassette on the print paper with the shaft (thicker one) around which the ink ribbon is wound located to the front. Align the arrows marked on the sides of ink cassette with those on the unit. Place the rear of the ink cassette along the guides that are provided inside the unit.

Make sure to set the ink ribbon roller to the ditches firmly. Turn the ivory roller to eliminate any slack.



Before Operation

2 · Push the ink cassette toward the back of the unit.
Hold the handle of the ink cassette and push it straight toward the back of the unit.
Then raise it until you hear a click to secure it in the ink cassette holder.

NOTE
If the ink ribbon is used up, repeat the steps 1 and 2 to replace the print paper and the ink ribbon.





3 · Push the center of the door to close.
The print paper setting is initialized two minutes after you close the door.
When the auto feed & cut mode has been selected, the FEED & CUT procedure is repeated three times after you close the door. When the print paper with the post card printing on its reverse side is installed, the FEED & CUT procedure is repeated five times.

NOTE
- When closing the door, push it until a click is heard.
- If the PAPER/INK RIBBON indicator illuminates when the door is closed, the print paper may have not been installed correctly.
  In this case, open the door to make sure that the print paper has been installed correctly. Then close the door again.
- On the auto feed & cut mode, when the print paper is installed more than three times, the print paper may be used up earlier than the ink ribbon.





When the manual & cut mode has been selected
When the manual feed & cut mode has been selected, hold down the FEED & CUT button for 1 second or longer. Repeat the manual feed & cut three times. When the print paper with the postcard printing on its reverse side is installed, repeat this procedure five times.
To select the auto feed & cut mode, see "Setting of the DIP switches"

Installation of the print paper and the ink ribbon is completed.

NOTE
· Make sure to replace the print paper and the ink ribbon at the same time.
· When replacing them, throw away the paper chips in the paper strip **bin.**

Error Messages & Countermeasures

OVERCOMING PAPER JAMS

1 · Press the DOOR OPEN button to open the door.
Make sure that the power is turned on before opening the door.
If the door does not open, turn off the power and turn it on again.
Then press the DOOR OPEN button again





2 · Remove the ink cassette.
Push down the ink cassette as shown by the arrow 1 and pull it out.

3 · Take out the print paper.
When taking the print paper out, pull it up toward you.



4 · Cut off the defective part of the print paper with scissors.

NOTE
Make sure to cut off the printed part of the print paper. Failure to do this may result in the ink ribbon sticking to the print paper and being torn.



5 · Install the print paper and the ink cassette with the ink ribbon.

6 · Push the center of the door to close.
The print paper setting is initialized two minutes after you close the door.
When the auto feed & cut mode has been selected, the FEED & CUT procedure is repeated three times after you close the door. When the print paper with the postcard printing on its reverse side is installed, the FEED & CUT procedure is repeated five times.

When the manual feed & cut mode has been selected, hold down the FEED & CUT button for 1 second or longer. Repeat the manual feed & cut three times. When the print paper with the postcard printing on its reverse side is installed, repeat this procedure five times.
For how to select the auto feed & cut mode, see "Setting of the DIP switches"



Cleaning

Cleaning as indicated below will help maintain stable printer operation and extend the printer's life.
Preparations:
Alcohol (isopropyl alcohol)
Tissue paper (Fold in half about four times, and use the folded side to clean.)
Other : Cleaner pen (option)*, Cleaning ribbon (option)*
* Please ask the dealer about options.



How to fold tissue paper



Cleaner pen

PREPARATIONS FOR CLEANING
1 Press the POWER button to turn on the power.
2 Press the DOOR OPEN button to open the door.
3 Remove the ink cassette.
4 Take out the print paper.
5 Press the POWER button to turn off the power.
Make sure to turn off the power before cleaning.

THERMAL HEAD CLEANING
Clean the heat-generating part below the thermal head. Wipe the head cleaning part carefully with tissue paper dampened with a small amount of alcohol.

NOTE
- Do not damage the thermal head.
- When the poor print quality is not corrected even if the head has been cleaned, replacement of the thermal head may be required. Contact your dealer.





CAUTION

· Thermal head is hot right after printing. Wait until the head is cold before cleaning the thermal head.

NOTE

· The thermal head may be damaged if you touch it while static electricity builds up on your body.

PAPER FLANGE CLEANING

Clean the parts that contact the print paper sides as shown above.Wipe the parts carefully with tissue paper dampened with a small amount of alcohol.

7-PLAYING

DEMONSTRATION

When there are no vends, the machine enters in Demo Mode. Photo samples are displayed. Once money is inserted, you are taken to the credit screen.

PRODUCT SCREEN

You can choose among 6 different products.

Photo ID

Color and Black & White

When the instructions conclude, you are given the option to choose "Color" or "Black & White" pictures.

SHOTS
4 Shots are taken.
(3 Shots if you activate the logo)

PRINTING
The pictures are shown on the screen while strips are printing.

Hairstyles

SELECT DESIRED LOOK
You can choose different hairstyle options.

SHOTS
Align your face with the circle on the screen.
Not bigger not smaller!



PRINTING
The pictures are shown on the screen while strips are printing.

Hats

FRAMES SELECTION
You can choose different frame options.



SHOTS
Align your face with the circle on the screen.
Not bigger not smaller!



PRINTING
The pictures are shown on the screen while the strips are printing.

Street Art

STREET ART SELECTION
Select one design.

PRINTING
The Street Art is not shown on the screen.

Get Framed

FRAME SELECTION
You can choose frame options.



PRINTING
The pictures are shown on the screen while the strips are printing.

8-CUSTOMIZED

8.1 STRUCTURE





1 · Necessary Materials:

USB Stick with 2 GB of available space
We recommend using a USB Stick with a led indicator

USB STICK Off (LED desactivated)

USB STICK On (LED activated)

USB STICK Blinking (LED activated)

8.2 LOGO

A FOLDER PhotoIdUpload



DIRECTIONS FOR UPLOADING THE LOGO



1 · Necessary Materials:
USB Stick with 2 GB of available space
We recommend using a USB Stick with a led indicator
(got to page 43)

2-Create a folder on the USB stick and name it **PhotoIdUpload**

3-Insert the logo that you want to use in the folder **PhotoIdUpload**

4-Connect the USB Stick to the Photo Booth

5-Go to Setup Menu (important) and confirm that logo is activated





Sample Logo

Logo Characteristics:

Name: Logo
Size: width: 800 pixels
height: 600 pixels
Resolution: 300dpi
Format: JPG

Not working? Please refer to section 13.1 for assistance
UPLOADING (See section 9)
SETUP MENU (See section 11)

8.3 WELCOME/BYE



DIRECTIONS FOR UPLOADING WELCOME/BYE



Welcome message (custom)



You must creat this folder

4 images
The names of the images must be: 1a,1b,1c,1d

Sample Welcome



Specifications:

4 images
(1a, 1b, 1c & 1d),
Each one with following characteristics:

Name: 1d
Size: width: 800 pixels
height: 600 pixels
Resolution: 72dpi
Format: JPG

Bye message (custom)



4 images
The names of the images must be: 1a,1b,1c,1d

Sample bye



Specifications:

4 images
(1a, 1b, 1c & 1d),
Each one with following characteristics:

Name: 1d
Size: width: 800 pixels
height: 600 pixels
Resolution: 72dpi
Format: JPG

UPLOADING (See section 9)
SETUP MENU (See section 11)



DIRECTIONS FOR UPLOADING WELCOME/BYE



Welcome message random



You must create this folder

The names of the images must be:
1a,1b,1c,1d
2a, 2b, 2c,2d
3a, 3b, 3c,3d

2 Samples Welcome random

Specifications:

(1a, 1b, 1c & 1d
2a, 2b, 2c & 2d
3a, 3b, 3c & 3d)
Each one with following characteristics:

Name: 1d
Size: width: 800 pixels
height: 600 pixels
Resolution: 72dpi
Format: JPG

Each player will get a different Random Welcome screen.

Bye message random

The names of the images must be:
1a,1b,1c,1d
2a, 2b, 2c,2d
3a, 3b, 3c,3d

2 Samples Bye random

Specifications:

(1a, 1b, 1c & 1d
2a, 2b, 2c & 2d
3a, 3b, 3c & 3d)
Each one with following characteristics:

Name: 1d
Size: width: 800 pixels
height: 600 pixels
Resolution: 72dpi
Format: JPG

UPLOADING (See section 9)
SETUP MENU (See section 11)

8.4 TEXT



DIRECTIONS FOR UPLOADING TEXT



All text in this file is printed vertically on the left side of the photostrips.

Sample: Rent your Booth (888). 888. 888 →

UPLOADING (See section 9)
SETUP MENU (See section 11)

8.5 MUSIC



DIRECTIONS FOR UPLOADING MUSIC

Name: BGmusic
Format: mp3

You can Upload any song to the PhotoBooth, the only thing you need to do is change the song's name to "BGmusic"and save the file into the "PhotoIdUpload" folder

UPLOADING (See section 9)
SETUP MENU (See section 11)

8.6 FRAMES





FRAMES

There are **3 screens** with frames. Each screen contains **6 groups**. That means, a total of **18 groups**.Every group of 4 frames will be printed together.

If you want to customize one group (for example number 1), you need four images (frames) 1a, 1b, 1c & 1d".

To create a new framework we will create a file with the following characteristics.

SAMPLE

Name: Check structure name
Size: width: 800 pixels
height: 600 pixels
Resolution: 300dpi
Format: PNG

It's very important to save the file of the frames only in PNG format.

Create your own customized frame. Inside of the blank area is where the camera will capture the image, and your customized frame will surround the image.

DIRECTIONS FOR UPLOADING FRAMES




PhotoIdUpload
You must create this folder
Frames
1a,1b,1c,1d
2a,2b,2c,2d
...
1
Screen 1 (group 1)
1a
1b
1c
1d

Screen1


1
1a
1b
1c
1d
2
2a
2b
2c
2d
3
3a
3b
3c
3d
4
4a
4b
4c
4d
5
5a
5b
5c
5d
6
6a
6b
6c
6d

Screen2



Screen3



Sample

If you want to customize the group N°1 follow this structure.





Sample

If you want to customize the groups N°1,2 & 3 follow this structure.



UPLOADING (See section 9)
SETUP MENU (See section 11)

8.7 ADVERTISING PHOTOS



DIRECTIONS FOR UPLOADING CUSTOMSHOTS



CUSTOMSHOTS are the images (made previous to the event) that we want to show on the screens during the event. An example could be for a wedding were the bride wants to show pictures from when the couple first met etc, or a company event, where they want to display brand names or products.

The CUSTOMSHOTS are shown Random during the Demonstration Mode.

Sample customshots

1

2

3

4

- You can put as many pictures as you want.
- The names of the images have to be: 1,2,3,4,5,6,7...

Specifications:

Name: 1
Size: width: 800 pixels
height: 600 pixels
Resolution: 72dpi
Format: JPG

UPLOADING (See section 9)
SETUP MENU (See section 11)

B **FOLDER**
PhotoIdEvents

CUSTOMIZED WEDDING

The HEADER is the image that apears on the top screen (1st screen) during the game.

1

Specifications:

Name: 1
Size: width: 800 pixels
height: 600 pixels
Resolution: 72dpi
Format: JPG

The image is placed at the top monitor number 1

· The name of the image must be: 1

UPLOADING (See section 9)
SETUP MENU (See section 11)

9-UPLOADING

1-Switch ON the Photo booth

2-Open the Photo slot door*

3-Insert the USB Stick to the PC (HP C2D) (the usb connection is on the left side of the PC)

4-Open the back door of your photobooth.

5-Press the yellow button from the Service Control Panel, to access the Setup Menu.

*** You will need 1314 keys (included on your photobooth)**

6-Press the yellow button for the menu

10-DOWNLOADING

C FOLDER PhotoIDownload

This folder is created automatically



If the logo is activated, you will have 3 shoots for each print, with the loaded logo printing in the fourth frame.

11-SETUP MENU

The setup menu is very useful for the owner of the Photo Booth. You can configure the Photo Booth depending on what kind of service you want to offer to your clients. You can control the timer, check the prices, adjust the camera settings or consult the accounting functions. To go to the setup menu while the Photo Booth is in Demo Mode, press the yellow button (Menu) from the Service Control Panel inside the Photo Booth.

· SETUP MENU SCREENSHOOTS



SETUP MENU CONFIGURATION

The configurable parameters are divided in 5 groups:

- Products & Prices
- Rentals
- Customize
- Options
- Camera

11.1 PRODUCTS & PRICES

You can set the prices of the different products.



SWITCH ON/OFF PRODUCT

You can enable/disable the products for each event

YES✓/NO✗



11.1.1 EXTRA COPIES

You can turn on the option of extra copies.





11.2 RENTALS

Free Play: YES✓ / NO ✗
Timer: YES ✓/ NO ✗
Start: 2012-X-X (Day) XX:XX(Hour)
Finish: 2012-X-X (Day) XX:XX(Hour)
Token: YES ✓/ NO ✗



11.3 CUSTOMIZE

To set up the Logo, the Welcome and Bye screens, the Fun frames, the Print date and the Print text.



11.3.1 LOGO



1-The menu is displayed on the screen.

2-Select customize and activate the logo with ✓ the green check mark.
(the logo will appear on the 3rd screen, if you can't see your logo it means that the upload is not correct.

3-Touch "X" EXIT. The Photobooth is ready to work

***It's very important that you use the exact specifications for the logo to work.**
Not working? Please refer to section 13.1 for assistance.

11.3.2 TEXT



1-The menu is displayed on the screen

2-Select customize and activate the text the ✔ green check mark.

3-Touch "X" EXIT.
The Photobooth is ready to work

11.3.3 DATE



1-The menu is displayed on the screen

2-Select customize and activate the text the ✔ green check mark.

3-Touch "X" EXIT.
The Photobooth is ready to work

11.3.4 WELCOME/BYE

1-The menu is displayed on the screen
2-Enter to the customized menu and select welcome/ Bye screen and CUSTOM
3-Touch "X" EXIT. The Photobooth is ready to work

WELCOME SCREEN



BYE SCREEN



11.3.5 FRAMES



1-The menu is displayed on the screen

2-Enter to the customized menu and select GET FRAMES and CUSTOM

3-Touch "X" EXIT. The Photobooth is ready to work

11.4 OPTIONS

Defines the parameters for some available features:
Current Time: 2012-X-X (Day) XX:XX(Hour)
Music on intro: YES✓/NO✗
Show events shots: Screen savers of photos already loaded by you. YES✓/NO✗
Internet: Upload the session shots to internet, Facebook and email (IMPORTANT: must be configurated) please go to number 12. YES✓/NO✗
Video message: Select this option to record a video (IMPORTANT: Internet must be activated). YES✓/NO✗
Touch screen Calibrate: Press twice the yellow button to access to the Setup Menu.
Automatically the menu is opened to calibrate the touch screen.



11.5 CAMERA

In the submenu CAMERA, the owner can set the camera zoom position and brightness.



12-INTERNET

12.1 PLAYER.GET YOUR PICTURE

Instructions on how to post pictures on Facebook, send emails, or watch a video.

1.You can find a code on the left of your photo.

2.Use this code on the web page, www.myphotocode.com

MEGT4DDYPT

www.myphotocode.com

3.A screen will appear where you can select the option that you want;
-Send an email.
-Watch a video.
-Post a picture on Facebook.



12.2 OWNER. PREPARE USB-STICK/EVENT

Do you want to customize logo, welcome, bye, text and music?
Send an email to myphotocode@dc-image.com

You will receive your username and password to **www.myphotocode.com**





A Prepare your USB

Manage your next event:
Customize for your next event the following things:

- **Choose the photobooth model where the USB will be plugged in.**
- **Upload your logo**
- **Upload your text (will be printed on a side of each print)**
- **Upload the Background music (played during the game)**
- **Customize your frames**
- **Customize Welcome screen**
- **Customize Bye Screen**
- **Customize the top screen banner and the images on demo screen.** *Strip photobooth only

B Event

Create a new event:
On this site you can create and manage your events.
Allow your costumers to share the photos on a personal website specially created for the occasion.

Manage your event schedule and customize your photobooth for each event.

- **Type the event name**
- **Select the dates.You can do a single day event or multi-day event**
- **Customize the background of myphotocode.com**
- **Choose who can view the photo shots – everybody or just the owners of the photos**

(More information See section 16)

13-TROUBLESHOOTING

· GENERAL PROBLEMS

Problem
The unit switch is ON, but it does not turn on

Causes
The unit is not plugged in.
The voltage is incorrect.
Overload: the fuse over the electric socket has been blown.

Solutions
Check if the unit is correctly connected to the electric ground.
Check if the electric ground is receiving electricity.
Be sure that the voltage is correct.
Change the fuse.

Problem
The fluorescent does not turn on.

Causes
The fluorescent lights have been blown.
The transformer has been blown.

Solutions
Replace the fluorescent lights (see above).
Replace the transformer

· MONITOR'S PROBLEMS

Problem
The monitor image looks darker or lighter

Causes
The monitor is not adjusted correctly.

Solutions
Readjust the monitor.

Problem
The monitor image moves up and down

Causes
The monitor is not adjusted correctly.

Solutions
Readjust the monitor.

·SOUND PROBLEMS

Problem
The sound does not work

Causes
The volume is not correct.
The configuration menu has the sound set to OFF.

Solutions
Adjust the volume with the control placed below the test, free-play and start buttons.
Change the sound configuration from the test menu (black button).

·PRINTER PROBLEMS

Problem
The printer does not print any photos

Causes
The printer is disconnected.
The printer is out of ink or paper.
The paper or the ink sheet was not properly installed.
Incorrect paper.
USB/ LPT Atmel chip position is incorrect.

Solutions
Switch on the printer.
Call the person in charge
Correctly place the paper and the ink.
Use only CK9550-DC type paper.

Problem
The printer does not switch on

Causes
The printer is disconnected.
The printer does not receive electric supply.

Solutions
Connect the printer.
Be sure that the cable is correctly connected.

Problem
It prints one or more white lines

Causes
Thermal head is broken.

Solutions
Replace thermal head.

·PC PROBLEMS

Problem
Install a brand new Control Board with Atmel chip and jumpers.

Causes
This problem is due to a hardware malfunction.
Check the green Capture Board, as it is probably out or half way in.

Solutions
Turn OFF the PC.
Take out the Capture Board. And put it again (all the way in).
Screw in tightly and check again that it is all the way in, and did not move little out during screwing.
Turn ON the PB and check it.

· **WARNING**
· If you have any doubts or any problems with the unit and it's performance, call a technician to solve the issue.

Printer	Cleaning. Check configuration.	Monthly
Glasses	Cleaning.	Weekly.
Control Panel	Check the functioning of all buttons	Monthly
Lights	Check the functioning of all the lights and the fluorescent light.	Monthly
Sound	Check the sound.	Monthly
Coin Acceptor Bill Acceptor	Clean and check the correct functioning	Annually
Interior	Cleaning	Annually
Exterior	Cleaning	Weekly

13.1 UPLOADING THE LOGO

PROBLEMS UPLOADING THE LOGO:

Possible causes:
1-USB STICK is damaged
2-The logo specifications/characteristics are not correct

1-USB is damaged
· Let's make a test to see if it works at the computer.
· Plug the USB STICK at the front of the PC (HP C2D), and go to Set Up Menu. Then exit the Menu.
· Take a picture by choosing the product you want.
· After the game, Remove the USB STICK.
· Plug the USB STICK in your PC or LapTop.
· Check if the USB STICK contents the **PhotoIdDownload** folder.
· It should be 2 folders into the PhotoIdDownload and your picture should be there.
· If your picture is not there, the USB STICK is not working properly.



It's recommended to use a USB drive with LED and 2GB of space.

2-The logo specifications/characteristics are not correct

- Plug the USB Stick in your PC or Laptop.
- Locate the logo, Placed on the logo and click the right button on your computer mouse to open properties.
- The properties should be as follows.

Click the right button

- **Check the logo specifications**





Logo specifications:

Name: Logo
Size: width: 800 pixels
height: 600 pixels
Resolution: 300dpi
Format: JPG

LOGO

Name: Logo

~~**Name:**~~
NOT ~~LOGO~~.JPG

If it doesn't work, consult a professional designer to assist in changing the logo.
ADVANCED USERS:
Use the following web site for suggestions;
http://www.webresizer.com/

13.2 HARD DRIVE

HARD DRIVE ERROR

This procedure is to check if the BIOS settings are correct for an Automatic BOOT-DVD.
WARNING!!! This procedure is very dangerous and could cause a PC Malfunction. Please read it carefully and follow all steps one by one.

1 · Plug in a Keyboard to the PC.
2 · Turn ON the PC (or the whole Photo Booth).
3 · When the ASRock screen appears, press "F10" several times until the "BIOS SETUP UTILITY" appears on the screen. If it does not come up, and the software continues uploading, then go back to the Step 2.





4 · With the Keyboard arrows, move up to the Storage Menu, here we are going to check the following thing:
· Device Configuration (step 5)
· Boot Order (step 6)

5 · Once you are inside the "**DEVICE Configuration**" please check the following points:

- "Hard disk" should be connected at SATA0
- "CD-ROM" should be connected at SATA1

If everything is OK, press ESC to return the Main menu.
If Hard disk or CD-ROM or Both are not detected, we should check the PC connections.(Do this work with the PC unplugged from power).Go to step 8



6 · Once you are inside the "**Boot Order**" please check the following points:

- "ATAPI CD-ROM"
- "Hard Drive"

If ATAPI CD-ROM or Hard Drive or Both are not detected, we should check the PC connections.(Do this work with the PC unplugged from power).Go to step 8



7 · With the Keyboard arrows, move right to the Advanced Menu here we are going to check the following thing:
· Select Power-On Option and confirm that the "After Power Loss" is ON

8 · Unplug the PC from the power.
9 · Open the top cover (there are 2 screws in the top back side of the PC)
10 · Check connections as follows:
Please pull up the green arrows from the DVD ROM and from the Power supply and check the connection as it shows in the following pictures.

IF The Hard Disk is SATA + DVD SATA it will be like this:





11・If all connections are fine (as it appears in the pictures), then it is possible that the component, which is not detected at the "IDE CONFIGURATION" Menu, is physically damaged. Please contact Digital Centre for a new part.

13.3 BOOT DVD

To Update the Machine or change the software version, please follow these steps:

1·Open the DVD Driver.
2·Insert the "Boot DVD".
3·Plug Off the Machine.
4·Plug On the Machine after 10 seconds.
5·Wait while the restore program reinstalls the
software (a progress bar appears on the screen).
The time process is about 30 minutes
6·A black screen appears when the process finishes.
7·Extract the DVD disk.
8·Plug Off the Machine.
9·Plug On the Machine after 10 seconds.
(In case that the Restore Program does not start automatically and
shows the message "Extract the dvd" immediately, then go to the
"Run the Restore Program Manually" (At the end of this Manual).

CUSTOMIZED FRAMES:
If you have customized frames and/or logos now is the time to upload.

1·Install the "Customized Frames DVD" into the DVD driver (CD or USB too).
2·Turn off the Machine.
3·Turn on the Machine after 10 seconds.
4·When the software is working in Demo, then go into the SETUP MENU, by
pressing the Yellow button at the Setup Control Panel. It will read the customized
frames and/or logos automatically before the software start.
5·Be sure to select LOGO=YES and the correct frames and Wait for the Setup Menu
save all changes. (Wait for the "Shut Down Please" message on the screen).
6·When the software runs in Demo again, you can extract the DVD, CD or USB,
and keep it to a safe place.
The NEW FRAMES are now working; you can go to Setup Menu and adjust the
Date at the correct position.

13.4 DONGLE ERROR

If you switch on the Photo booth and the following message appears; "Sentinet HASP key not found (H0007)", it means that the printer dongle is not well connected. The USB dongle must be connected on P.7 (please see picture).



P.7 USB Extension
AM / AF From Dongle to
PC. (180 cm - Inch 70,87)

P.7

P.7 USB Extension
AM / AF From Dongle to
PC. (180 cm - Inch 70,87)

13.5 CAMERA ERROR

When you take a picture and your screen appears black please check the USB connection from the camera. The USB must be connected on P.10 (please see picture).

P.10 USB Extension AM / AF From Camera to PC.
(180 cm - Inch 70,87)

13.6 TOUCH SCREEN ERROR

If the power card is properly plugged then the LED is green.

If the power card is properly plugged then the LED is blue.



13.7 PRINTER ERROR

Problem
When you take a picture and see this message Error "INVALID PRINTER" on the screen

Error number 0:
- The printer is disconnected.
- Look at the "PIN" if the correct printer

Error number 2:
- The printer is disconnected.
- Look at the PIN of the correct printer.

Error number 3:
- The paper or the ink sheet was not properly installed.

Error number 4:
- The printer Dongle is disconnected.

The "Please Wait" error is very common. It looks like the PC freezes, but it isn't. The problem is that the computer is waiting for the right components.

When we turn on the Photo Booth, the computer shows the "Please Wait" screen while it checks the Control Board, the USB adapter and the Printer. If any of the components are not ok, the software doesn't go ON.

So, when we face this problem we have to check the 3 components. The procedure is as Follows:

1 · Check the Printer lights ON. Should be ON the following lights "POWER" and "READY". If any other light, please fix it and Turn OFF and ON the Photo Booth.

2 · Check the Printer Connections. Power and USB, just 2 wires.



3 · Check the Control Board Serial Connection. (That is the common problem Point). (attached 2 pictures: Correct and Error "Please Wait"). This connection is very easy to lose during transport, or when we work at that area.

13.8 NO SIGNAL

Check if the PC lights are ON.
If the lights are on then it appears that the Photobooth is working but the monitor is not.
Next steps:
When you turn ON the Photobooth, can you see any message on the screen? (ex; manufacturer name, or "NO SIGNAL")?
If this is the case, the VGA cable is probably unplugged or damaged.
But if nothing appears on the screen (when you turn ON the Photobooth), please check if there is power to the Monitor. Power cable is probably unplugged from the monitor.

13.9 CONTROL BOARD ERROR

The control Board is the green board located behind the PC. It doesn't mean that the Control Board is bad; it could mean that the PC could not connect with the Control Board (because the Serial cable is not correctly connected).

Check following points:
1 · Check the Control Board Serial Connection "P.2". (That is the common problem point).(attach 2 pictures: Correct and Error "Please Wait"). This connection is very easy to lose during transport, or when you work at that area.
2 · If all connections are good, then check that the Control Board Red LED is ON.
3 · If all the 2 points are OK, but still doesn't work, please send the Control Board to Digital Centre (contact the Support Team before sending)



P.2 Serial Cable From PC to Control Board . STRIP (200 cm - Inch 78,74)

P.2 Serial Cable From PC to Control Board . STRIP (200 cm - Inch 78,74)

13.10 IMAGE ADJUSTING

If the image is moved please follow the instructions:



A- Press “Menu” (1)



B- Press “Down” three times (3)

C- Press “ok” (4)

D- Press “ok” (4) Auto Adjust

E- Press “Down” (3) Monitor Adjust



14-CHARACTERISTICS

14.1 CONTROL BOARD DIAGRAMS



PIN NUMBER	SIGNAL	REMARKS
1	GND	
2	12V	
3,4,5	N.C.	
6	BLOCQUING	U7 PUT THIS TO >= 3v WHEN THE PROGRAM LETS YOU TO USE COINS. MINOR THAN 1v WHEN MC
7	COIN PULSE CHANEL 1	U12 PULSE TIME DURATION > 50 msc
8	COIN PULSE CHANEL 2	U4 THE PROGRAM DOESN'T USE IT
9	COIN PULSE CHANEL 3	U14 THE PROGRAM DOESN'T USE IT
10	COIN PULSE CHANEL 4	U5 THE PROGRAM DOESN'T USE IT

14.2 DECALS

You can use images of 300 dpi to personalize the decals if needed. Save in a JPG format.

The size cm (for EUR) or inch (for USA) for each one must be:
1-(DE3400) DECAL. STRIP #1 Bottom Left Lateral Door (Photo Slot)
(30x23 cm - Inch 9,1x11,8)

MAGNETS
1-Thanksgiving (55,5x80,5 cm - Inch 21,9x31,7)
2-Thanksgiving (55,5x78 cm - Inch 21,9x30,7)

MAGNETS

1 **Thanksgiving**
(55,5x80,5 cm - Inch 21,9x31,7)

1 **(DE3400)** Bottom Left Lateral (Photo slot)
(30x23cm - Inch 9,1x11,8)

(DE3400) DECAL. STRIP #1 Bottom Left Lateral Door (Photo Slot)

2 **Thanksgiving**
(55,5x78 cm - Inch 21,9x30,7)

14.3 SPARE DIAGRAMS

GL3400
SCREEN GLASS 19"

ME3414
TILTING CAMERA FRONT HOLDER.
(WHITE)

ME3402
MAIN BODY TOP
CHASSIS 2
MONITORS.
STRIP (WHITE)

EL3400
FULL HD CAMERA.

ME3404
TOP BACK
DOOR 2
MONITORS.
STRIP (WHITE)

PL3400
"LOOK HERE"#3 PLASTIC RIGHT
ARROW. STRIP (7,5x10 cm - Inch 2,96x3,94)

PL3401
"LOOK HERE"#3 PLASTIC
LEFT ARROW. STRIP
(7,5X10 CM
INCH 2,96X3,94)

GL3401
TOUCH SCREEN GLASS 19"

EL3404
LCD MONITOR 19''
HANNS

EL3405
LED STRIP WHITE
COLOUR - 12 LEDS.
(30,5 cm - Inch 12)

GL3401
TILTING CAMERA
BACK HOLDER.
(RAW METAL)

CO0007
ICT DOLLAR
BILL ACCEPTOR 12V

ME3423
COVER PLATE FOR BILL
ACCEPTOR HOLE. STRIP
(WHITE) (15x4cm
Inch 5.91x1.57)

ME3413
STAND UP 4
MONITORS LOCK.
STRIP (ALUMINUM)

ME3406
MAIN BODY LEFT
LATERAL DOOR
(PHOTO SLOT). STRIP
(WHITE)

ME3411
BACK METAL
HANDLE

ME0001
LOCK 1314

ME3401
MAIN BODY
BOTTOM
CHASSIS
2 MONITORS.
STRIP (WHITE)

PL0003
LATERAL PLASTIC
HANDLE. STRIP
(BLACK)

ME3426
BOTTOM FRONT
FLOOR. STRIP
(ALUMINUM)

ME3400
MAIN BODY BACK
CHASIS. (WHITE)

ME3403
BOTTOM BACK
DOOR
2 MONITORS.
STRIP (WHITE)

ME3428
RIGHT LATERAL
METAL COVER.
STRIP (WHITE)
(10,5x11 cm
Inch 4,13x4,33)

PL0016
POLYURETHARE
WHEEL D-100. (STRIP)

14.4 PARTS LIST

CA0006	BILL READER CABLE ICT-DC. 12V (92,5 cm - Inch 36,41)
CA0007	BILL READER CABLE MEI-DC. 110V
CA2902	POWER CORD 110V - USA
CA2912	POWER CORD 230V - EUR
CA3400	MAIN POWER CABLE (4 MONITORS + PC + PRINTER). STRIP
CA3402	VGA CABLE M/M. (180 cm - Inch 70,87)
CA3403	VGA CABLE M/M. (150 cm - Inch 59,06)
CA3404	VGA CABLE M/M. (100 cm - Inch 39,37)
CA3405	VGA CABLE M/M. (300 cm - Inch 86,61)
CA3407	USB EXTENSION AM/AF. (180 cm - Inch 70,87)
CA3409	VGA CABLE TO 4 MONITORS
CA3410	CABLE FROM CONTROL BOARD TO SERVICE PANEL + SPEAKERS + LED
CA3411	INTERNAL PC 12V DIVIDER
CA3412	TOUCH CABLE FROM TOUCHBOARD TO USB PC & 12V ADAPTOR (200cm - Inch 78.74)
CA3413	TOUCH CABLE 12V ADAPTER (44cm - Inch 17.32)
CA3414	USB CABLE FROM PRINTER TO PC. AM/BM (180 cm - Inch 70,87)
CA3415	LED CABLE. (BLACK) (53 cm - Inch 20,87)
CA3416	JACK STEREO CABLE. (180 cm - Inch 70,87)
CA3417	USB CABLE AM/AF-PANEL. STRIP (50 cm - Inch 19,69)
CA3418	TOUCH CABLE FROM TOUCHBOARD TO USB PC + 12V ADAPTOR TOGETHER (225cm - Inch 88.58)
CA3422	SERIAL CABLE FROM PC TO CONTROL BOARD. STRIP (200 cm - Inch 78,74)
CO0007	ICT DOLLAR BILL ACCEPTOR 12V
CO3408	ICT DOLLAR BILL ACCEPTOR SET (DBA+WIRE+12V DIVIDER+METAL BRACKET). STRIP (WHITE)
DE3400	DECAL. STRIP # 1 - BOTTOM LEFT LATERAL DOOR (30x23 cm - Inch 9,10x11,80)
EL0001	LED-ATMEL CHIP (only chip)
EL3400	FULL HD CAMERA
EL3401	CONTROL BOARD V3.0 EVO LED (110V)
EL3402	CONTROL BOARD V3.0 EVO LED (220V)
EL3403	LED-ATMEL CHIP ON CONTROL BOARD WITH SOFTWARE EVO LED
EL3404	LCD MONITOR 19'' HANNS
EL3405	LED STRIP WHITE COLOUR - 12 LEDS. (30,5 cm - Inch 12)
EL3406	FILTER 2 FUSES STANDARD 6A
EL3407	TOUCH BOARD
EL3408	FAN (2 UNITS 12V) TWIN
EL3409	SERVICE CONTROL PANEL - MODEL 2
EL3410	SPEAKERS 1W. (7,5 cm - Inch 2,95)
EL3411	LED STRIP CONNECTO M/M (FROM EL3405 TO CA3415)
EL3417	TRANSFORMER 2A 12V
GL3400	SCREEN GLASS 19"
GL3401	TOUCH SCREEN GLASS 19''
ME0001	LOCK 1314
ME0002	KEY FOR LOCK 1314
ME3400	MAIN BODY CHASSIS. STRIP (WHITE)
ME3401	MAIN BODY BOTTOM CHASSIS 2 MONITORS. STRIP (WHITE)
ME3402	MAIN BODY TOP CHASSIS 2 MONITORS. STRIP (WHITE)
ME3403	BOTTOM BACK DOOR 2 MONITORS. STRIP (WHITE)
ME3404	TOP BACK DOOR 2 MONITORS. STTRIP (WHITE)
ME3405	MAIN BODY BACK DOOR. STRIP (WHITE)
ME3406	MAIN BODY LEFT LATERAL DOOR (PHOTO SLOT). STRIP (WHITE)

ME3407	MONITOR 19'' HOLDER. STRIP (RAW METAL)
ME3408	MONITOR 19" (4th) HOLDER FOR FUTURE EXPANSION. STRIP (RAW METAL)
ME3409	PRINTER HOLDER CP9550DC. (RAW METAL)
ME3410	PC HP-C2D HOLDER. (RAW METAL)
ME3411	BACK METAL HANDLE
ME3412	CHASSIS MONITOR'S LOCKER FOR TRANSPORT. STRIP (WHITE)
ME3413	STAND UP 4 MONITORS LOCK. STRIP (ALUMINUM)
ME3414	TILTING CAMERA FRONT HOLDER. (WHITE)
ME3415	TILTING CAMERA BACK HOLDER. (RAW METAL)
ME3417	PRINTER DONGLE BRACKET. (INOX)
ME3418	LED SUPPORT - 6 HOLES. (RAW METAL) (2,5x28 cm - Inch 0,98x11,02)
ME3420	EXPANSION BASE REFORCEMENT. (WHITE)
ME3422	EXPANSION BRACKET. (WHITE)
ME3423	COVER PLATE FOR BILL ACCEPTOR HOLE. STRIP (WHITE) (15x4 cm - Inch 5,91x1,57)
ME3425	ICT METAL PLATE SUPPORT. STRIP (WHITE)
ME3426	BOTTOM FRONT FLOOR. STRIP (ALUMINUM)
ME3428	RIGHT LATERAL METAL COVER. STRIP (WHITE) (10,5x11 cm - Inch 4,13x4,33)
PC0001	DONGLE USB SECURITY AND SOFTWARE
PC0004	RAM MEMORY MODULE. DDR2 5300 667 (512Mb)
PC0005	HARD DRIVE SATA
PC0006	DVD READER SATA
PC0007	PC PROCESSOR HP-C2D
PC0008	PC MOTHER BOARD HP-C2D
PC0009	PC POWER SUPPLY HP-C2D
PC0011	PC HP-C2D (WITHOUT VIDEO CARD 4 MONITORS)
PC0013	PC BUTTON BATTERY 2032
PC0016	VIDEO CARD 4 MONITOR
PL0003	LATERAL PLASTIC HANDLE. STRIP (BLACK)
PL0005	METHACRYLATE DC. STRIP (BLUE) (14x54 cm - Inch 5.51x21.21)
PL0016	POLYURETHANE WHEEL D-100. (STRIP)
PL3400	"LOOK HERE" #3 PLASTIC ARROW RIGHT. STRIP (7,5x10 cm - Inch 2,96x3,94)
PL3401	"LOOK HERE" #3 PLASTIC ARROW LEFT. STRIP (7,5x10 cm - Inch 2,96x3,94)
PR9550	PRINTER MITSUBISHI CP9550DW-DC
SC3408	WHEELS SET SCREW. STRIP
SE3402	TRANSFORMER SOCKET PLASTIC BASE. (WHITE)
SE3411	COVER ON THE ROAD. STRIP (BLUE)
TO0002	ALLEN WRENCH
WO3400	WOOD PC BASE. STRIP (RAW)
WO3401	WOOD PRINTER BASE. STRIP (RAW)
SC3422	PCB FOOT
ME3424	PALLET ANCHORAGE. (RAW METAL)
PK3400	CARDBOARD BOX PACK. STRIP (59x72x124 cm - Inch 23,23x28,35x48,82)
PK3401	WOOD PALLET. STRIP (89x61 cm - Inch 28,74x35,03)
PL0001	RUBBER BAND PROTECT TO FALLING DOWN THE MONITOR
PL0002	BOOT DVD PLASTIC HOLDER
PL3402	CABLE RACK PLASTIC. (WHITE) (38,5x5 cm - Inch 15,15x1,96)
PL3403	CABLE RACK PLASTIC. (WHITE) (67x5 cm - Inch 26,37x1,96)

15-NOTES

DIGITAL DC CENTRE

The Worldwide PhotoBooth Manufacturers

MyPhotoCode.com

CONTENTS

1. Myphotocode.com----------96

2. Manage your USB set up----------97
2.1 How to login----------98-99
2.2 Create a new USB set up----------100-101
2.3 How to customize----------101-106
2.3.1 Logo----------101
2.3.2 Text on a side of each print----------102
2.3.3 Background music----------103
2.3.4 Frames----------103 -104
2.3.5 Welcome Screen----------105
2.3.6 Bye Screen----------105
2.3.7 Top Screen Banner----------106
2.3.8 Custom images on demo screen----------106

2.4 Download the USB set up----------107

3. Manage your online events----------108
3.1 How to create an online event----------108
3.2 Manage the online event----------109 -114
3.2.1 Photos----------113-114
3.2.2 Emails----------114
3.2.3 Edit----------114

4. Warning----------115

1-MYPHOTOCODE.COM

MyPhotoCode.com is a website thinking for Owners and Customers.

WHAT CAN THE OWNER DOES THROUGH OUR WEBSITE MYPHOTOCODE.COM?

- Create an USB Set Ups for customize their Photo booth
- Create an Online Event
    - Edit an event
    - Recover the event pictures
    - Upload and share your pictures on Facebook, twitter or send copies by e-mail

WHAT A CUSTOMER CAN DOES THROUGH OUR WEBSITE

When the customer take's a picture, you can see a code on the side.
If you introduce this code in the website, you can recover any picture and share it through different social webs, and also, send copies by e-mail.

2. MANAGE YOUR USB SET UP



1. You need a username and password to access to MyPhotoCode.

2. You need identify your Photo booth to get a username and password.

3. To know the identification number, please, take a photo and send us the number that appears in the right side of the strip, to the following address:

myphotocode@dc-image.com

Then, we will send you the username and password, use them to login.

2.1 HOW TO LOGIN

1- Goes to http://myphotocode.com and click on RENTAL LOGIN, it is up in the right side

2- Please, enter your username and password and click ENTER



3- Here you can prepare the USB to customize our Photo Booth . Click on "USB Set Ups"


Home
Hello, from here you can
manage you USB Set Ups r
the Online Events.
If you need help, download the here!
Click on USB Set Ups

4- Click on "Add New"



2.2 CREATE A NEW USB SET UP

1- Fill in the information :

- Name: Choose a name for your USB, for example "Night Party" or "Luca's wedding".
- Photo Booth: Open the list and selected your photo booth, click the arrow to see all the options.
- Online event: You can link the USB with a created online event or created another! (See section "**3.1 How to create an online event**")
- Save it!


Create a new USB Set Up.
Name
Used to identify the USB Set Up in the list.
Photo booth
Choose the photo booth model where the USB will be plugged in.
Strip
Online Event
Is the Photo booth going to be linked to any Online Event?
If so, choose it from the list of already created events.
Not linked
Save!
Cancel
» Go back to USB Set Ups
» Download the USB Set Up into a USB Drive
1
Typing a NAME
2
Click on the arrow to see the box with all Photo booths. Select your Photo booth.
Online Event
Is the Photo booth going to be linked to any Online Event?
If so, choose it from the list of already created events.
Not linked
Not linked
Save!
Cancel
Photo booth
Strip
Strip
Mega In
Wall Strip
Party'n'go
temp booth
NG V&N
Mega Out

2- When the USB has been created we can start to customize.
Click on "Start editing its content".

2.3 HOW TO CUSTOMIZE

You can customize the next parameters:

2.3.1 Logo
2.3.2 Text on a side of each print
2.3.3 Background music
2.3.4 Frames
2.3.5 Welcome Screen
2.3.6 Bye Screen
2.3.7 Top Screen Banner (wedding version) *Only STRIP Photo booth
2.3.8 Custom images on demo screen

2.3.1 LOGO: image format .JPG to 300 dpi.

2.3.2 TEXT: This is the text that will appear in every strip. You can write all that you want. Look down here and see example, the text appears in the right side along the strip.



Example:


Text
This is the text line which will be printed on a side of each print.
Go to www.digital-centre.com – Rent a PhotoBooth at "Reno Say

2.3.3 BACKGROUND MUSIC: You can upload music . Maximum 5 MB. Must be mp3 format. Look down here and see example, the text appears in the right side along the strip.

2.3.4 FRAMES: You have three options

- None
- Upload custom
- Select premade frames from list



- **NONE:** we don't upload any new frame

• **UPLOAD CUSTOM:** select 4 frames from our computer. The frames must be in .png format.



• **SELECT PREMADE FRAMES FROM LIST:** we can choose frame from the list of myphotocode. You can see this frames before choose. You can see this frames before choose.



Select one, and press SAVE.

2.3.5 WELCOME SCREEN: There are 2 options:

- Single
- Random

We can upload "Welcome" Images through our computer.
Remember that Images must be in .jpg to 72 dpi.

2.3.6 BYE SCREEN: We have 2 options again:

- Single
- Random

We can upload "GoodBye" Images through our computer.
Remember that Images must be in jpg to 72 dpi



2.3.7 TOP SCREEN BANNER (WEDDING VERSION) *Only STRIP Photo booth

2.3.8 CUSTOM IMAGES ON DEMO SCREEN

2.4 DOWNLOAD THE USB SET UP

Download the USB Set Up: when you finish customizing, save the changes.
Download the USB Set Up.

Click on "Download the USB Set Up into a USB Drive".
It will appear a new window asking what want you do?
Select Save and accept.

a- Save the document 'save-in-sub.zip" in the USB pen drive. Don't change the document name when you save it.

b- This is an compacted document, that you must decompress in the USB pend drive.

c- When you finish the decompress, you'll have 2 folders called "PhotoIdUpload" and "PhotoIdEvents".

d- Inside the USB you only must have these two folders: PhotoIdUpload i PhotoIdEvents.
e- When we have our USB with these folders, connect the USB to the Photo Booth.

IMPORTANT! : Enter in the configuration menu and go out to update the new changes and customizations.

3-MANAGE YOUR ONLINE EVENTS

Click on Online Events Option.


DIGITAL DC CENTRE
Hello Sample User! Logout.
Home
Hello, from here you can
manage your USB Set Ups or
th Online Events.
If you need help, download the MyPhotoDate Rentals Tutorial here!

It will open a new window with a list about our events online.
This list it's empty because there isn't any event created.

3.1 HOW TO CREATE AN ONLINE EVENT

Click on "Add New"



3.2 MANAGE THE ONLINE EVENTS

Edit the options:

- **Event title:** Try a name to the event, for example: Night Party
- **Start Date:** Indicate when it starts and how long is the event
- **Background:** You can put on a different background to show in the event online, when some user take's a picture and want to recover it, they only have to enter the code in the website Myphtocode. Instead the background of the web, they could see our personal background..
- **Private pictures:**
    - If the event is a private event, when the users insert their code, they only will see their photos.
    - If the event isn't private, when the user introduces the code, could see all the pictures of the event.
- **Single day event:** Indicate if the event is for a single day
- **Available Online:** If the user choose YES, the picture will be seen on the website, otherwise, the pictures won't be seen online.



Select Background: we can choose one of the predefined backgrounds or upload another one. If we upload a background it must be in .jpg or .png to 72 dpi. This image will be repeated.



In case of we upload our logo

At the moment to see the pictures, the logo, will be seen like this:



When we finish the configuration, click on SAVE.

We have already edited i created the online event!


DIGITAL DC CENTRE
Home » Online Events » Edition
Edit the Online Event.
Online Event edited successfully.
» Go back to Online Events.

Select "Go back to Online Events
Return to outset where the list was empty, but now we can see our new event


DIGITAL DC CENTRE
Hello Sample User! Logout.
Home Online Events
Manage the Online Events.
Sort by: Date Name
Date Name Photo booth Status Photos Videos Actions
2012/8/29 Night Party Online 0 0 Photos | Emails | Edit
Add new

Here you can see all the information about the event that we just created:

- Date : The day of the appointment
- Name: the name that we gave to the event
- Photo booth: the photo booth model that will be used in the event. This section will be empty until the moment we take the first photo, then, the model will appear automatically.
- Status: indicate if online option is activated
- Photos: how many pictures has been taken
- Video: how many videos has been recorded
- Actions:
    - **3.2.1 Photos:** can see the pictures from all the users
    - **3.2.2 Emails:** can see the mail list where the users send the photos
    - **3.2.3 Edit:** you can edit the event again

3.2.1 Photos: you will see a new window with all the photos in a little size.


DIGITAL DC CENTRE
Hello tester DC! Logout.
Home Online Events Photos
These are the photos of the Online Event.
» Post all photos to Facebook
Go back

If you click one of the small photos, this will be opened and some options appear. In this example, the user didn't record any video, so the possible options are:

- Post on Facebook
- Send by email
- Tweet photo

But the options are different when the user records a video:

- Watch the video
- Post on Facebook
- Send by email
- Tweet photo



3.2.2 Emails: Select the Button "ACTIONS **>** EMAIL" you will see an address list, here you could see the sending historial, every time that users share their photos by e-mail, the e-mail addresses will be registred in this list.



3.2.3 Edit: See section "**3.1 How to create an online event**"

4. WARNING

WARNING!

Remember, to get the photos, by Myphotocode.com, the photobooth must be connected to internet.

If there isn't connection to internet, you can save the photos in a empty USB memory in the computer.

When the USB will be detect by the computer, will be create automatically a New Folder called PhotoIdDownload.
Inside the PhotoIdDownload folder you will find 2 folders more, the first one called "Myphotocode" with your images and videos inside (just in case that you have recorded a video) and the second one called "Shots" with the individual shots.

Once the event finish, you can take off the USB memory from de computer and use it in any other computer to see your images or videos.



If the logo is activated, you will have 3 shoots for each print, with the loaded logo printing in the fourth frame.

The WorldWide PhotoBooth Manufacturers